

Multi-functional Flow Control Valve for Water Treatment Systems

63504E (F116A1)

63604E (F116A3)

63502E (F117A1)

63602E (F117A3)

User Manual



Please read this manual in details before using the valve and keep it properly in order to consult in the future 0WRX.466.649

Before the valve put into use, please fill in the below content so as to help us to refer in the future.

The Program Type Setting (Operation by professional)

When all symbols light on, press and nhold buttons for 5 seconds to enter the menu of valve model selection. Please set the program type in accordance with the product type.

Softener System Configuration

Tank Size Dian	nm; Height	mm;		
Resin VolumeI	.; Brine Tank Cap	pacity	_L;	
Hardness of Raw Water_	mmol/L;	Pressure of In	let Water	MPa;
Control Valve Model	; Numbe	т	_;	
The Specification of Drain	n Line Flow Contro	ol	_;	
The Specification of Brine	e Line Flow Contro	oll	_;	
Injector No		⊸ ?		
Water Source: Ground-wa	iter Filtered Gro	und-water 🗆 T	ap Water Othe	r

Parameter Set

Parameter	Unit	Factory Default	Actual Value
Control Mode A-01(02, 03,04)	1	A-01	
Unit Mode HU-01(02, 03)	1	HU-01	
Water Treatment Capacity (Meter type)	m³	10:00	
Service Days(Time of clock type, by days)	D	03	
Service Hours(Time clock type, by hours)	Н	20	
Regeneration Time	7	02.00	
Backwash Time	min.	10	
Brine & Slow Rinse Time	min.	60	
Brine Refill Time	min.	05	
Fast Rinse Time	min.	10	
Interval Regeneration Days	D	30	
Output Mode b-01/2	1	b-01	

• If there is no special requirement when purchase F116, we choose 9# injector and no drain line flow control for the standard configuration, for F117, 7# injector and 8468062 drain line flow control for the standard configuration.

Catalogue

Notice	I
1. Product Overview	2
1.1. Main Application & Applicability	2
1.2. Product Characteristics	
1.3. Service Condition	
1.4. Product Structure and Technical Parameters	5
1.5. Installation	6
2. Basic Setting & Usage	9
2.1. The Function of PC Board	9
2.2. Basic Setting & Usage	.11
3. Applications	
3.1. Softener Flow Chart	.14
3.2. The Function and Connection of PC Board	
A. Signal Output Connector	.15
B. Interlock	
C. Pressure Relief Output	.18
D. Remote Handling Connector	.19
E. Interlock System	.19
F. Series System	.20
3.3. System Configuration and Flow Rate Curve	.20
3.4. Parameter Settlement	.22
3.5. Parameter Enquiry and Setting	.24
3.6.Trial Running	
3.7.Trouble-Shooting	
3.8. Assembly & Parts	
4. Warranty Card	

Notice

- To ensure normal operation of the valve, please consult with professional installation or repairing personnel before use it.
- If there are any of pipeline engineering and electric works, there must be finished by professional at the time of installation.
- Do not use the control valve with the water that is unsafe or unknown quality.
- Depending on the changing of working environment and water requirement, each parameter of softener should be adjusted accordingly.
- When the water treatment capacity is too low, please check the resin. If the reason is shortage of resin, please add; if the resin turns reddish brown or broken, please replace.
- Test water periodically to verify that system is performing satisfactorily.
- Sodium used in the water softening process should be considered as part your overall dietary salt intake. Contact doctor if you are on a low sodium diet.
- Ensure that there is solid salt all the time in the brine tank in the course of using, when this valve is used for softening. The brine tank should be added the clean water softening salts only, at least 99.5% pure, forbidding use the small salt.
- Do not put the valve near the hot resource, high humidity, corrosive, intense magnetic field or intense librations environment. And do not leave it outside.
- Forbidden to carry the injector body. Avoid to use injector body as support to carry the system.
- Forbidden to use the brine tube or other connectors as support to carry the system.
- Please use this product under the water temperature between $5\sim50\,^{\circ}$ C, water pressure $0.15\sim0.6$ MPa. Failure to use this product under such conditions voids the warranty.
- If the water pressure exceeds 0.6MPa, a pressure reducing valve must be installed before the water inlet. While, if the water pressure under 0.15MPa, a booster pump must be installed before the water inlet.
- It is suggested to install PPR pipe, corrugated pipe or UPVC pipe, instead of TTLSG pipe.
- Do not let children touch or play, because carelessness operating may cause the procedure changed.
- When the attached cables of this product and transformer are changed, they must be changed to the one that is from our factory.

1.Product Overview

1.1. Main Application & Applicability

Used for softening or demineralization water treatment systems.

Be suitable for

Residential softening system,

Ion exchange equipment

Boiler softening water system

RO pretreatment softening system, etc.

1.2. Product Characteristics

Simple structure and reliable sealing

It adopts hermetic head faces with high degree pottery and corrosion resistance for opening and closing. It combines with Service, Backwash, Brine & Slow Rinse, Brine Refill and Fast Rinse.

- No water pass the valve in regeneration in single tank type.
- Manual function

Realize regeneration immediately by pushing manual button at any time.

Long outage indicator

If outage overrides 3days, the time of day indicator "@"will flash to remind people to reset new time of day. The other set parameters do not need to reset. The process will continue to work after power on.

LED dynamic screen display

The stripe on dynamic screen flash, it indicates the control valve is in service, otherwise, it is in regeneration cycle.

Buttons lock

No operations to buttons on the controller within 1 minute, button lock indicator light on which represent buttons are locked. Before operation press and hold "a" and "" " the buttons for 5 grounds to unlock. This fountiers are result in course to a service.

"Thebuttons for 5 seconds to unlock. This function can avoid incorrect operation."

• It can choose time clock type or meter type by program selection

When all symbols light no, press and hold "②" and "⑤" buttons for 5 seconds to enter the menu of valve model selection. Please set the program type in accordance with the product type. (Tim clock type by days or hours or meter type) (Notice: The meter type product has one flow meter and flow meter cable, but the time clock type doesn't have).

• Four kinds of meter type can be selected (Suite for F116A3, F117A3)

Model	Name	Instruction
A-01	Meter Delayed	Regenerate on the day although the available volume of treated water drops to zero (0). Regeneration starts at the regeneration time.
A-02	Meter Immediate	Regenerate immediately when the available volume of treated water drops to zero(0).
A-03	Intelligent Meter Delayed	Meter Delayed Regeneration type, but by setting Resin Volume, Feed Water Hardness, Regeneration Factor, the controller will calculate the System Capacity.
A-04	Intelligent Meter Immediate	Meter Immediately Regeneration Type, but by setting Resin Volume, Feed Water Hardness, Regeneration Factor, the controller will calculate the System Capacity.

• There are two kinds of regeneration modes for time clock type

When the program is set as time clock type by days (such as F116A1, F117A1, etc.) it can be changed to be by hours by dialing the red switch on main control board to "I" (Refer to the P14). Pointing to "ON" means the time clock type service by days. (Attention: After dialing the switch, please restart the power)

● Interlock function


It has a function of interlock to realize only one valve in regeneration but the other valves are in service while several valves parallel in system. In multi-steps treatment systems such as RO pre-treatment, when several valves are in series, there is only one valve in regeneration or washing to ensure pass water all the times while different valves in regeneration or washing.(Application refer to Figure 3-9)

● Signal output

There is a signal output connector on the main control board. It is for controlling external wiring (Refer to Figure from Figure 3-1 to Figure 3-8).

There are two kinds of output modes:

b-01 Mode: Turn on start of regeneration and shut off end of regeneration; b-02 Mode: Signal available only at intervals of regeneration cycles and In service.



Remote handling input

This connector can receive external signal, used together with PLC, and computer etc. to control the valve.(Application refer to Figure 3-11).

Pressure relief output

The valve will cut off feeding water to drain line when it switches in regeneration cycles(Same as signal output b-02). Thus in some water treatment system, e.g. Deep Well, one booster pump was installed on the inlet to increase the system water feeding pressure, this cut-off will cause pressure on inlet rising too fast to damage the valve. Pressure Relief Output can be used to avoid this problem. (Application refer to Figure 3-10).

Maximum interval regeneration days

Under the situation of service reaching the setting days and the volume not yet, it could enter into regeneration process forcibly when current time is the same as regeneration time.

All parameters can be modified

According to the water quality and usage, the parameters in the process can be adjusted.

1.3. Service Condition

Runxin Valve should be used under the below conditions:

	Items	Requirement	
Working conditions Working environment	Water pressure	0.15MPa ~ 0.6MPa	
	Water temperature	5℃ ~50℃	
Working environment Relative	Environment temperature	5°C ~ 50°C	
	Relative humidity	\leq 95% (When temperature is 25°C)	
	Electrical facility	AC100 ~ 240V/50 ~ 60Hz	
	Water turbidity	< 5FTU	
Inlat water	Water hardness	First Grade Na+ 6.5mmol/L; Second Grade Na+ 10mmol/L	
Inlet water quality	Free chlorine	< 0.1 mg/L	
	Iron ²⁺	< 0.3mg/L	
	(CODMn)	<2mg/L (O ₂)	

In the above table, First Grade Na⁺represents First Grade Na⁺Exchanger. Second Grade Na⁺represents Second Grade Na⁺Exchanger.


• When the water turbidity exceeds the conditions, a filter should be installed on the inlet of control valve.

• When the water hardness exceeds the conditions, the hardness of treated water can not meet the requirement of boil water (0.03 mmol/L, should adopt secondary softening.


1.4. Product Structure and Technical Parameters


A.Product Structure(The appearance is just for reference. It is subjected to the real product.)

F116A1 dimensions:



Note:F116A1 assemble a flow meter to be F116A3 meter type. F117A1dimensions:





Note:F117A1 assemble a flow meter to be F117A3 meter type.

OD—Outer Diameters, 1.05OD=26.7mm

B.Technical Parameters

Transformer Output: DC12V/1.5A

Model Connection	ection	Flow Rate m ³ /h	1 Mar 17 (1977)			
Model	Inlet/ Outlet	Drain	Brine Line Connector	@0.15MPa	Remark	
F116A1	100	2/4//3/4	2 70 70 1	M.	Down-flow, time clock type	
F116A3	1"M	1"M 3	3/4"M	3/4"M 3/8"M	4	Down-flow, meter type
F117A1	0 / 4 mm	S 1105 P	2/0//2 5	281	Down-flow, time clock type	
F117A3	3/4"F	3/4"M	3/8"M	2	Down-flow, meter type	

Remark: M-Male thread, F-Female thread

1.5.Installation

A. Installation notice

Before installation, read all those instructions completely. Then obtain all materials and tools needed for installation.

The installation of product, pipes and circuits should be accomplished by professional to ensure the product can operate normally.

Perform installation according to relevant pipeline regulations and the specifi cations of Water Inlet, Water Outlet, Drain Outlet, Brine Line Connector.

B. Device location

- ①The filter or softener should be located close to drain.
- ②Ensure the unit is installed in enough space for operating and maintenance.
- 3Brine tank need to be close to softener.
- (4) The unit should be kept away the heater, and not be exposed outdoor. Sunshine or rain will cause the system damage.
- ⑤Please avoid to install the system in one Acid/Alkaline, Magnetic or strong vibration

circumstance, because above factors will cause the system disorder.

- ⑥ Do not install the filter or softener, drain pipeline in circumstance which temperature may drop below 5°C, or above 50°C.
- Tone place is recommended to install the system which causes the minimum loss in case of water leakage.

C. Pipeline installation

- ①Install control valve
- a. As the Figure 1-1 shows, select the riser pipe with 26.7mm OD, glue the riser pipe to the

bottom strainer and put it into the mineral tank, cut off the exceeding tube out of tank top opening. Plug the riser tube in case of mineral entering.

- b. Fill the mineral to the tank, and the height is accordance with the design code.
- c. Remove the tap covering on the central tube and check if the riser tube is on the central of tank.
- d. Install the top distributor to the valve and insert the riser tube into control valve and screw tight control valve.

Note:

• The length of riser tube should be neither higher

2mm nor lower 5mm tank top opening height, and its
top end should be rounded to avoid damage of O-ring inside the valve.



Figure 1-1

- Avoid floccules substance together with resin to fill in the mineral tank.
- · Avoid O-ring inside control valve falling out while rotating it on the tank.

2 Install animated connector

As Figure 1-2 shows, put the sealing ring into nut of animated connector, and screw in water inlet.

3 Install flow meter

As Figure 1-2 shows, put the sealing ring into nut of flow meter, screw in water outlet; insert the sensor into flow meter.




Figure1-2

4 Pipeline connection

a.As Figure 1-3 shows, install a pressure gauge in water inlet.

b.Install valve A, B, C and D in the intermediate pipeline, inlet and outlet valve D is a sampling valve. (Or adopt F70A/F70C bypass valve).

c.Install a check valve on outlet.

d.Inlet pipeline should be in parallel with outlet pipeline. Support inlet and outlet pipeline with fixed holder.

Note:

- · If the water outlet or water tank is installed higher than control valve or parallel interlock system with multi-outlets, a liquid level controller must be installed in brine tank. Or else, the water in water outlet or water tank will flow backwards into brine tank when backwash.
- · If making a soldered copper installation, do all sweat soldering before connecting pipes to the valve. Torch heat will damage plastic parts.




Figure1-3

- · When turning threaded pipe fittings onto plastic fitting, use care not to cross thread or broken valve.
- If the valve belongs to time clock type, there are no step 2 and 3.

5Install drain pipeline

a.As the Figure 1-4 shows, slide the drain hose connector into drain outlet.

b.Locate the drain hose well as the Figure 1-4 show.

Note:

· Control valve should be higher than drain outlet, and be better not far from the drain hose.(If the drain port is higher than control valve, a check valve should be installed on drain outlet. Or else, the drain water will flow back to outlet in brine refill.)

· Be sure not connect drain with sewer, and leave a certain space between them, avoid wastewater




Figure1-4


be absorbing to the water treatment equipment, such as showed in the Figure 1-4.

©Connect brine tube

- a. As Figure 1-5 shows, slide 3/8" brine tube hose connector over end of brine tube.
- b.Insert tube bushing into the end of brine tube.
- c. Tighten brine draw hose connector onto brine line connector.
- d.Connect the other end of brine tube with the brine tank. (The liquid level controller and air-blocker should be installed in the brine tank.)


Note:

The brine tube and drain pipeline should not be bended or plugged.



2. Basic Setting & Usage

2.1. The Function of PC Board



- ●A. " @" Time of day indicator
- "" Light on, display the time of day.
- "12:12" flash, remind you to reset the time of day if electrical service interrupted 3 days more (If electrical service interrupted within 3 days, it doesn't need to reset the time.)
- ●B. "₺" Button lock indicator
- " &" Light on, indicate the buttons are locked. At this moment, press any single button will not work (No operation in one minute, " & " will light on and lock the buttons.)
- Solution: Press and hold both "♥" and "♥" for 5 seconds until the "₺" light off.
- ●C. " ॐ" Program mode indicator
- " \odots " Light on, enter program display mode. Use " \odots " or " \odots " to view all values.
 - " Stash, enter program set mode. Press " " or " " to adjust values.
- Press "●", "ॐ" light on, enter program display mode and use " ♥ " or "♥" to view all values.
- In program display mode, press " " , " " flash, enter program set mode, press " " or " " and adjust values.
- Press "after all program are set, and then the voice "Di" means all setting are success and return program display mode.
- ●E. " @ " Manual/Return button
- Press " in any status, it can proceed to next step.(Example: If outlet water is unqualified, press " in Service status, it will start regeneration cycles instantly; Press " while it is in Backwash status, it will end backwash and go to Brine &Slow Rinse at once.)
- Press " in program display mode, and it will return in Service; Press " in program set mode, and it will return program display mode.
- Press " " while adjusting the value, then it will return program display mode directly without saving value.
- ●F.Down " ② " and Up " ② "
- In program display mode, press " O " or " O " to view all values.
- In program set mode, press " O " or " O " to adjust values.
- Press and hold both " and " for 5 seconds to lift the Button Lock status.


2.2. Basic Setting & Usage

• A. Parameter specifications

Function	Indicator	Factory Default	Parameter Set Range	Instruction		
Time of Day		Random	00:00~23:59	Set the time of day when use; ":" flash.		
			A-01	Regenerate on the day although the available volume of treated water drops to zero (0). Regeneration starts at the regeneration time.		
			A-02	Regenerate immediately when the available volume of treated water drops to zero(0).		
Control Mode	A-01	A-01	A-03	Meter Delayed Regeneration type, but by setting Resin Volume, Feed Water Hardness, Regeneration Factor, the controller will calculate the System Capacity. Regeneration mode same as A-01.		
			A-04	Meter Immediately Regeneration Type, but by setting Resin Volume, Feed Wate Hardness, Regeneration Factor, the con roller will calculate the System Capacity Regeneration mode same as A-02.		
Unit Mode	HU-01	HU-01	01,02,03	01-m³; 02-gal; 03-L		
Service Days	2	1-03D	0∼99 Days	Only for Time Clock Type, regeneration by days.		
Service Hours	\$	1-20H	0∼99 Hours	Only for Time Clock Type, regeneration by hours.		
Regeneration Time	02:00	02:00	00~23:59	Regeneration time; ": " light on.		
Resin Volume	20L	20L	5-500L	Resin volume in brine tank (L)		
Feed Water Hardness	Yd1.2	1.2	0.1-9.9	Feed water hardness (mmol/L)		
Exchange Factor	AL.65	0.65	0.30-0.99	Relate to the raw water hardness. When hardness is higher, the factor is smaller.		
Water Treatment Capacity	Z	10m³	0∼99.99m³	Water treatment capacity in one circle(m ³)		
Backwash Time	111	10min.	0~99.59	Backwash time(Minute)		
Brine & Slow Rinse Time		60min.	0~99.59	Brine & Slow rinse time(Minute)		
Fast Rinse Time	***	10min.	0~99.59	Fast rinse time(Minute)		
Brine Refill Time	U	5min.	0~99.59	Brine refill time(Minute)		

Maximum Interval Regeneration Days	H-30	30	0~40	Regenerate on the day even through the available volume of treated water do not drop to zero
Output Control Mode	b-01	01	01 or 02	Mode 01: Signal turn on start of regeneration and shut off end of regeneration. (Connection refer to the Figure P5) Mode 02: Signal available only intervals of regeneration cycles and in service. (Connection refer to the Figure P5)

●B. Process Display (Take A-01 as an example)



• Illustration:

- In Service status, the figure shows A/B/C/D; In Backwash status, it shows figure E/C; In Brine& Slow Rinse status, it shows F/C; In Fast Rinse status, it shows figure G/C; In Brine Refill status, it shows figure H/C. In each status, every figure shows 15 seconds.
- Above displays are taking the Meter Type for example. For the Time Clock Type, it shows the rest days or hours, such as 1-03D or 1-10H.
- The display screen will only show "-00-" when the electrical motor is running.
- The time of day figure" That continuously, such as "12:12" flash, indicates long outage of power. It reminds to reset the time of day.
- The display will show the error code, such as "-E1-" when the system is in error.
- Working process: Service→ Backwash→ Brine & Slow Rinse → Fast Rinse → Brine Refill →Service.

C. Usage

After accomp lishment of the installation, parameter setting and trial running, the valve could be put into use. In order to ensure the quality of outlet water can reach the requirement, the user should complete the below works:

① Ensure that there is solid salt all the time in the brine tank in the course of using when this valve is used for softening. The brine tank should be added the clean water softening salts only, at least 99.5% pure, forbidding use the small salt and iodized salt.

Press and hold both " and" on "for 5 seconds to lift the lock status. Press " nand the " nand the " nand the nand the nand the nand the control mode. If it shows A-01 or A-02, press " nand the digital area will show the given water treatment capacity(If the control mode shows A-03 or A-04, then press" nand the digital area will show the feed water hardness); Press" nand nand digital flash. Press" nand hear a sound "Di", then finish the adjustment. Press" nand turn back the service status.


The estimation of water treatment capacity, you can refer to the professional application specification. When select A-03 or A-04 intelligent control mode, the control will automatically calculate the water treatment capacity by setting resin volume, feed water hardness and regeneration factor.

④ For A-01 or A-03 control mode (Delayed regeneration type), please pay attention to whether the time is current or not. If the time is not right, you can adjust as follow: After lifting the lock status, press" ② ", the" ② "and" ⑥ "light on. Then press" ② ", the" ③ " and hour value flash. Press" ② "or" ⑥ "continuously, reset the hour value; Press " ② " again, " ③ " and minute value flash. Press" ② " or" ⑥ " continuously, reset the minute value; Press " ② " and hear a sound "Di", then finish the adjustment. Press" ② " exit and turn back the service status.

The regeneration parameters have been set when control valve left factory. Generally, it does not need to reset. If you want enquiry and modify the setting, you can refer to the professional application specification.


3. Applications

3.1. Softener Flow Chart



3.2. The Function and Connection of PC Board

Open the front cover of control valve, you will see the main control board and connection port as below:



The main functions on main control board:

Function	Application	Explanation
Signal output	Outlet solenoid valve	If system strictly require no hard water flow from outlet or controlling the liquid level in water tank.
connector b-01	Inlet pump	Increase pressure for regeneration or washing. Use the liquid level controller to control inlet pump to ensure there is water in tank.
Signal output connector b-02	Inlet solenoid valve or inlet pump	When inlet pressure is high, it needs to close water inlet when valve is rotating to protect motor.
Pressure relief connector	Control the inlet bypass to release pressure	When valve is rotating, pressure relief connector opened to prevent pressure increasing rapidly.
Interlock connector	To ensure only one control valve regeneration or washing in system.	Use in RO Pre-treatment, water supply together but regeneration in turn. Second grade ion exchange equipment, etc.
Remote handling connector	Receipt signal to make the control rotate to next circle.	It is used for on-line inspection system, PC connection, and realize automatically or remote controlling valve.

A. Signal Output Connector

Control Solenoid Valve (Set b-01)

① Solenoid valve on outlet controls water level in brine tank. Instruction: If system strictly require no hard water flow from outlet in regeneration cycle(Mainly for no hard water flow out when valve is switching or valve in backwash or brine drawing positions), a solenoid valve could be installed on outlet, the wiring refer to Figure 3-1.




Figure 3-1 Wiring of Solenoid Valve on Outlet


Function:

When valve in service status, if soft water tank is short of water, solenoid valve is open to supply soft water, but if water tank has enough water, solenoid valve us closed, so no soft water supplied.

When the valve in backwash status, there is no signal output. So, solenoid valve is closed, and now water flow into soft water tank.

②Solenoid Valve on Inlet (Set b-02)

Instruction: When inlet pressure exceeds 0.6MPa, install a solenoid valve on inlet. Control mode is b-02. Pressure relieved when valve switching, the wiring refer to Figure 3-2. As Figure 3-3 shows, it also can use the pressure relief port to work.



Function:

When inlet pressure is high, install a solenoid valve on inlet to ensure valve switching properly. When valve is exactly at position of Service, Backwash, Brine& Slow Rinse, Fast Rinse and Brine Refill, solenoid valve is open. When valve is switching, solenoid valve is closed, no water flow into valve to ensure valve switching properly. It could prevent the problem of mix water and water hammer.

Use interlock cable to realize valves in parallel and series in same system which is suited for RO pretreatment system or second grade Na+ system. The wiring refer to Figure 3-4.




Figure 3-4 Wiring of Solenoid Valve on Inlet

2). Liquid Level Controller controls Inlet Pump(Two-phase motor)(Set b-01)

Instruction: For the system using well or middle-tank supplying water, switch of liquid level controller and valve together control pump opening or closing. The wiring refer to Figure 3-5.




Figure 3-5 Wiring of Liquid Level Controlling Inlet Pump

Function:

When valve in service status, if water tank is short of water, start up pump, but if water tank has enough water, the switch of liquid level controller is closed, so pump doesn't work.

When valve in regeneration cycle, inlet always has water no matter what is water condition in water tank. As Runxin valve no water pass outlet in regeneration cycle, it ensure no water fill into brine tank.

A liquid switch at the top opening O well or in middle water tank in RO system protect pump from working without water in case of out of raw water.

3). Liquid Level Switch in Water Tank Controls Inlet Pump (Three-phase) (Set b-01)

The principle is the same as for two-phase's, only change single-phase into three-phase motor, and use an AC contactor (Refer to Figure 3-6).





Figure 3-6 Wiring of Liquid Level Switch in Water Tank Controls Inlet Pump

4). Control Inlet Booster Pump (Set b-01 or b-02)

Instruction: If inlet water pressure is less than 0.15MPa, which makes rinse drawing difficult, a booster pump is suggested to be installed on inlet. Control mode b-01. When system in regeneration cycle, booster pump is open, the wiring refer to Figure 3-7.IF the booster pump current us bigger than 5A, system need to install an contactor, the wiring refer to Figure 3-8.






Figure 3-7 Wiring of Booster Pump on Inlet

Figure 3-8 Wiring of Booster Pump on Inlet

B. Interlock

Instruction:

In the parallel water treatment system, it ensure only one valve in regeneration or washing cycle and (n-1) valves in service, that is, realizing the function of supplying water simultaneously and regenerating individually.

In the series and parallel water treatment system (Second grade Na+Exchanger or RO pre-treatment system), it ensure only one valve in regeneration or washing cycle and there is/are water(s) in service. refer to Figure 3-9.




Figure 3-9 Network System Wiring with Interlock Cable

Note: Use Interlock Cable to connect CN8 to CN7 on next valve in the loop.

One system with several valves, if interlock cable is disconnected, the system is divided into two individual system.

C. Pressure Relief Output

Runxin valve will cut off feeding water to drain line when it switches in regeneration cycles. Thus in some water treatment system, e.g. Deep Well, one booster pump was installed on the inlet to increase the system water feeding pressure, this cut-off will cause pressure on inlet rising too fast to damage the valve. Pressure Relief Output can be used to avoid this problem. The wiring refer to Figure 3-10.




Figure 3-10 Wiring of Pressure Relief Output

Figure 3-11 Wiring of Remote Input

D. Remote Handling Connector

Used for making pure water, connected with online monitory system or PC machine: when the conductivity or other parameter reach the setting valve or PC machine give the signal, need regeneration. It can give the signal to the remote handling connector of the main control board to let it regenerate by signal time. The connector receives the signal is same as handle press. The wiring refer to Figure 3-11.

E.Interlock system

2 or more than 2 valves are interlocked connecting in one system and all valves are in service but regenerate individually. The wiring refer to Figure 3-12.




Figure 3-11 Interlock System

Figure 3-12 Series System

● F.Series System

This is a 2 or more than 2 valves system, all in service, with one flow meter for the entire system. For the time type valve, the regeneration time should be set and adjusted to the Max; for the volume type valve, connect its signal output connector with the remote handle connector of the time-type valve. That can realize the function of supplying water simultaneously and regenerating orderly. The wiring refer to Figure 3-13.

3.3. System Configuration and Flow Rate Curve

A. Product Configuration

1 Product configuration with tank, resin volume, brine tank and injector.


Tank Size (mm)	Resin Volume (L)	Flow Rate (t/h)	Brine Tank Size (mm)	The Minimum Salt Consumption for Regeneration (Kg)	Injector Model	Control Valve Mode
$\varphi180\times1130$	16	0.5	φ 250 × 520	2.40	6202	
ф 205 × 1300	25	0.7	ф 390 × 810	4.00	6303	
ф 255 × 1390	40	1.2	ф 390 × 810	6.00	6304	F117
ф 300 × 1650	60	1.8	ф 450 × 940	9.00	6207	
ф 355 × 1650	100	2.5	ф 500 × 1060	15.00	6307	
ф 255 × 1390	40	1.2	ф 390 × 810	6.00	6306	
ф 300 × 1650	60	1.8	φ 450 × 940	9.50	0300	
ф 355 × 1650	100	2.5	ф 500 × 1060	15.00	6308	F116
ф 400 × 1650	120	3.5	ф 500 × 1160	18.00	6200	
ф 450 × 1650	150	4.5	ф 500 × 1160	22.50	6309	

Note: The flow rate calculation is based on linear velocity 25m/hr; the minimum salt consumption for regeneration calculation is based on salt consumption 150g / L (Resin).


B. Flow Rate Characteristic

1).Pressure-flow rate curve

F117:



F116:



2) Injector parameter table

Inlet Pressure	Draw Rate (L/M)								
		F117		F116					
MPa	6303 Yellow	6304 Blue	6307 Purple	6306 Black	6308 Red	6309 Green			
0.15	1.95	2.37	3.08	3.73	4.78	5.77			
0.20	2.28	2.70	3.52	4.27	5.58	6.68			
0.25	2.52	3.02	3.88	4.78	6.28	7.37			
0.30	2.75	3.33	4.27	5.27	6.80	8.10			
0.35	2.95	3.55	4.63	5.67	7.37	9.70			
0.40	3.15	3.75	4.92	6.07	7.65	9.18			

3) Configuration for standard injector and drain line flow control

tor	Draw Rate	Slow Rinse BLFC Optiona		DLFC Model	Back- wash / Fast Rinse	Contro Valve Model		
			L/m	L/m			L/m	
175 ~ 200	6303	Yellow	2.75	1.66	8468076, 8468075, 8468057, 8468056, 8468052, 8468053(Standard).	8468042	7.33	
225 ~ 250	6304	Blue	3.33	2.18	8468076, 8468075, 8468057, 8468056, 8468052, 8468053(Standard).	8468060	8.83	F117
300 ~ 350	6307	Purple	4.27	3.03	8468076, 8468075, 8468057, 8468056, 8468052, 8468053, 8468054, 8468055 (Standard).	8468062	16.83	
250 ~ 300	6306	Black	5.27	3.31	8468076, 8468075, 8468057, 8468056, 8468052, 8468053, 8468054(Standard).	8468077	1.14	
325 ~ 350	6308	Red	6.80	4.28	8468076, 8468075, 8468057, 8468056, 8468052, 8468053, 8468054, 8468055 (Standard).	8468062	1.49	F116
400 ~ 450	6309	Green	8.10	5.23	8468076, 8468075, 8468057, 8468056, 8468052, 8468053, 8468054, 8468055 (Standard).	No DLFC	1.88	

Remark: Above data for the product configuration and relevant characteristics are only for reference. When put in practice, please subject to the different requirements of raw water hardness and application.


4) Brine line flow control parameter table

No.	8468076	8468075	8468057	8468056	8468052	8468053	8468054	8468055
Flow RateL/m	0.30	0.58	0.68	1.32	1.55	2.95	5.00	5.67

3.4. Parameter Settlement

①Service timeT1

Water treatment capacity



2 Backwash time T2

It is subject to the turbidity of inlet water. Generally, It is suggested to be set 10~15 minutes. The higher the turbidity is, the longer backwash time can be set. However, if the turbidity is more than 5FTU, it should be better to install a filter in front of the exchanger.

(3)Brine& slow rinse time T3

$$T3=(40 \sim 50)H_R$$
 (min)
Generally, $T3=45H_R$ (min)

In this formula, H_R—— The height of resin in exchange tank (m.)

4)Brine refill timeT4

Down-flow regeneration: $T4 = 0.45 \times V_R \div Brine refill speed (min.)$

Up-flow regeneration: $T4 = 0.34 \times V_R \div Brine refill speed (min.)$

In this formula: V_n —Resin volume(m^3)

The Brine refill speed is related to inlet water pressure. It is suggested to lengthen 1~2 minutes of calculated brine refilling time to make sure there is enough water in tank. (The condition is that the there is a level controller installed in the brine tank) (5) Fast rinse time T5

$$T5=12 \times H_R \pmod{n}$$

Generally, the water for fast rinse is $3 \sim 6$ times of resin volume. It is suggested to be set $10 \sim 16$ minutes, but subject to the outlet water reaching the requirement.

©Exchange factor

Exchange factor = $E/(k\times1000)$

In this formula, E—Resin working exchange capability(mol/m 3)it is related to the quality of resin. Down-flow regeneration, take 800 ~ 900. Up-flow regeneration, take 900 ~ 1200.

K—Security factor, always take $1.2 \sim 2$. it is related to the hardness of inlet water: the higher the hardness is, the bigger the K is.

7Regeneration time


The whole cycle for generation is about two hoursPlease try to set up the regeneration time when you don't need water according to the actual situation.

The calculation of parameters for each step is only for reference, the actual proper time will be determined after adjusting by water exchanger supplier. This calculation procedure of softener is only for industrial application; it is not suitable for small softener in residential application.

3.5. Parameter Enquiry and Setting

3.5.1. Parameter Enquiry

When "\(\xi \)" light on, press and hold both "\(\& \)" and "\(\varphi \)" for 5 seconds to lift the button lock status; then press "\(\textit{n} \)" and "\(\sigma \)" light on, enter to program display mode; press "\(\textit{n} \)" or "\(\varphi \)" to view each value according to below process.(Press "\(\textit{n} \)" exit and turn back to service status)



3.5.2.Parameter Setting

In program display mode, press "and enter into program set mode. Press "and or "and to adjust the value."

3.5.3. The Steps of Parameter Setting

Items	Process steps	Symbol
Time of Day	When time of day "12:12" continuously flash, it reminds to reset; 1.Press "a" to enter into program display mode; both "and" "symbol light on,": "flash 2. Press "a", both "and hour value flash, through "and" "or" "to adjust the hourvalue; 3. Press "a" again, both "and hour value flash, through "and" "or" "to adjust the minute value; 4. Press "a" and hear a sound "Di", then finish adjustment, press "and to turn back.	<i>0 8:3 0</i> ⊙ &

Control Model	1.In control mode display status, press "a" and enter into program set mode, "and 01 value flash; 2. Press "o" o" set the value to be A-01, A-02, A-03 or A-04 control mode; 3. Press "a" and hear a sound "Di", then finish adjustment, press "a" to turn back.	8 - 0 1
Unit Mode	1.In unit mode display status, press "a" and enter into program set mode, "and 01 value flash; 2.Press o "or o", and choose from the m3/L/gal; 3. Press and finish adjustment, press to turn back.	× U - 0 1 -
Regen- eration Time	1.In regeneration time display status, press "a" and enter into program set mode. "and 02 flash; Press" or "a" to adjust the hour value; 2.Press a "again, and 00 flash, press or "a" to adjust the minute value; 3. Press and hear a sound "Di", then finish adjustment, press "a" to turn back.	0 2:0 0
Water Treatment Capacity	1. In water treatment capacity display status, it shows "∑" and 10.00. Press "ஹ" and enter into program set mode. "⊘" and 10.00 flash 2. Press "ஹ" or "ஹ" to adjust the water treatment capacity value(m3); 3. Press "ஹ" and hear a sound "Di", then finish adjustment, press "ஹ" to turn back.	10.00
Resin Volume	1. In resin volume display status, it shows 100L. Press "" and enters into program set mode. "" and 100 value flash; 2. Press "" or "" o" to adjust the volume value(L); 3. Press "" and hear a sound "Di", then finish adjustment, press "" to turn back.	188.
Feed Water Hardness	1. In feed water hardness display status, it shows yd1.2. Press "and enter into program set mode. "O," and 1.2 value flash; 2. Press "O" o" o" to adjust the hardness value (mmol/L); 3. Press "O" and hear a sound "Di", then finish adjustment, press "O" to turn back.	y a 1.2 ⊗
Exchange Factor	1. In exchange factor display status, it shows AL.55. Press "and enter into program set mode. "and 55 flash; 2. Press "a" to adjust the exchange factor value; 3. Press "a" and hear a sound "Di", then finish adjustment, press "a" to turn back.	R L.5 5 ⊗
Backwash Time	1. In backwash time display status, it shows "iii" and 2-10. Press "and enter into program set mode. "and 10:00 flash; 2. Press or or or to adjust the backwash time; 3. Press "a" and hear a sound "Di", then finish adjustment, press "b" to turn back.	2-10:00 # %

Brine& Slow Rinse Time	1. In brine& slow rinse time display status, it shows "\"and 3-60:00. Press "\"and and enter into program set mode. "\"\"and 60:00 flash; 2. Press \"\"\"or \"\"or \"\"or \"or \"or \"or \	3-8 0:0 0 # &
Fast Rinse Time	1. In fast rinse time display status, it shows "H" and 4-10:00. Press "D" and enter into program set mode. "D and 10:00 flash; 2. Press or or or to adjust the fast rinse time; 3. Press "D" and hear a sound "Di", then finish adjustment, press "D" to turn back.	Y- 10:0 0
Brine Refill Time	1. In brine refill time display status, it shows "\(\delta\)" and 5-05:00, Press "\(\textit{2}\)" and enter into program set mode. "\(\textit{2}\)" and 05:00 flash; 2. Press "\(\textit{2}\)" or "\(\textit{2}\)" to modify the brine refill time; 3. Press "\(\textit{2}\)" and hear a sound "Di", then finish adjustment, press "\(\textit{2}\)" to turn back.	S-0 5:0 0
Maximum Interval Regener- ation Days	1. In maximum Interval regeneration days display status, it shows H-30. Press "a" and enter into program set mode. "and 30 flash; 2. Press "a" or "o" to adjust the Interval regeneration days; 3. Press "a" and hear a sound "Di", then finish adjustment, press "a" to turn back.	ж - 30° ®
Signal Output Mode	1. In signal output mode display status, it shows b-01. Press "②" and enter into program set mode."②" and 01flash; 2. Press "③" or "③" to adjust the b-02; 3. Press "③" and hear a sound "Di", then finish adjustment, press " to turn back.	8 - 8 1

For example, the fast rinse time of a softener is 12 minutes. After regenerating, the chloridion in the outlet water is always higher than normal, indicating that there is not enough time for fast rinse. If you want the time to set to 15 minutes, the modification steps as follows:

- ①Press and hold both "O" and "O" to lift the button lock status(light off)
- ②Press "@", "@;" and light on;
- ③Press "♠" or "♠" continuously until" ight on. Then the digital area shows: 4-12M;
- 4Press"@"," 23 and 12 flash;
- ⑤Press"②" continuously until 12 changed to 15;
- ⑥Press "②", there is a sound "Di" and the figure stop flashing; the program back to enquiry status
- The following of the steps from the enquiry stat, the display will show the current service status.

3.6. Trial running

After installing the multi-functional flow control valve on the resin tank with the connected pipes, as well as setting up the relevant parameter, please conduct the trial running as follows:

A.Close the inlet valve B & C, and open the by-pass valve A. After cleaning the foreign materials in the pipe, close the bypass valve A. (As Figure 1-3 shows).

B.Fill the brine tank with the planned amount of water and adjust the air check valve. Then add solid salt to the tank and dissolve the salt as much as possible.

C.Switch on power. Press " and go in the Backwash position; when " iii " light on, slowly open the inlet valve B to 1/4 position, making the water flow into the resin tank; you can hear the sound of air-out from the drain pipeline. After all air is out of pipeline, then open inlet valve B completely and clean the foreign materials in the resin tank until the outlet water is clean. It will take 8~10 minutes to finish the whole process.

D.Press ", turning the position from Backwash to Brine Slow Rinse; " ight on and enter in the process of Brine Slow Rinse. The air check valve close when control valve finished sucking brine, then slow rinse start to work. It is about 60 ~ 65 minutes for whole process.

F.Press " \blacksquare " to Brine refill position. " \blacksquare " light on and it indicates the brine tank is being refilled with water to the required level. It takes about $5\sim 6$ minutes, then add solid salt to the brine tank.

G.Press "s", making the control valve return to Service Status; "\$\overline{\Z}\$" light on and start to running.

Note:

- When the control valve enter into the regeneration status, all program can be finished automatically according to the setting time; if you want one of steps terminated early, you can press "
 ".
- If water inflow too fast, the media in tank will be damaged. When water inflow slowly, there is a sound of air emptying from drain pipeline.
- After changing resin, please empty air in the resin according to the above Step C.
- In the process of trial running, please check the water situation in all position, ensuring there are no resin leakage.
- The time for Backwash, Brine& Slow Rinse, Fast Rinse and Brine Refill position can

be set and executed according to the calculation in the formula or suggestions from the control valve suppliers.

3.7. Trouble-Shooting

A. Control Valve Fault

Problem	Cause	Correction		
1.Softener fails to regenerate.	A.Electrical service to unit has been interrupted. B.Regeneration cycles set incorrect. C. Controller is defective. D. Motor fails to work.	A.Assure permanent electrical service (check fuse, plug, pull chain or switch). B. Reset regeneration cycles: C. Replace controller. D. Replace motor.		
2.Regeneration time is not correct.	A.Time of Day not set correctly. B. Power failure more than 3 days.	Check program and reset time of day,		
3.Softener supply hard water.	A. Bypass valve is open or leaking. B. No salt in brine tank. C. Injector plugged. D.Insufficient water flowing into brine tank. E.Leak at O-ring on riser pipe. F. Internal valve leak. G.Regeneration cycles not correct. H. Shortage of resin. I. Bad quality of feed water or turbine blocked.	A. Close or repair bypass valve. B.Add salt to brine tank and maintain salt level above water level. C. Change or clean injector. D. Check brine tank refill time. E.Make sure riser pipe is not cracked. Check oring and tube pilot. F. Change valve body. G.Set correct regeneration cycles in the program H.Add resin to mineral tank and check whether resin leaks. I. Reduce the inlet turbidity, clean or replace turbine.		
4.Softener fails to draw brine.	A. Line pressure is too low. B. Brine line is plugged. C. Brine line is leaking. D. Injector is plugged. E. Internal control leak. F. Drain line is plugged. G.Sizes of injector and DLFC not match with tank.	A. Increase line pressure. B. Clean brine line. C. Replace brine line. D. Clean or replace new parts. E. Replace valve body. F. Clean drain line flow control. G. Select correct injector size and DLFC according to the P22 requirements.		
5.Unit used too much salt.	A. Improper salt setting. B. Excessive water in brine tank.	A.Check salt usage and salt setting. B. See problem no.6.		
6.Excessive water in brine tank.	A. Overlong refilling time. B.Foreign material in brine line. C. Foreign material in brine valve and plug drain line flow control. D. Not install safety brine valve but power failure whiling salting. E. Safety brine valve breakdown.	A. Reset correct refilling time. B.Check brine line. C. Clean brine valve and brine line. D. Stop water supplying and restart pr install safety brine valve in salt tank. E. Repair or replace safety brine valve.		
7.Pressure lost or iron in conditioned water.	A.Iron in the water supply pipe. B. Iron mass in the softener. C. Fouled resin bed. D.Too much iron in the raw water.	A. Clean the water supply pipe. B.Clean valve and add resin cleaning chemical, increase frequency of regeneration. C. Check backwash, brine draw and brine tank refill. Increase frequency of regeneration and backwash time. D.Iron removal equipment is required to install before softening.		

8.Loss of mineral through drain line. A. Air in water system. B. Bottom strainer broken. C. Improperly sized drain line control.		A.Assure that well system has proper air eliminator control. B. Replace new bottom strainer, C. Check for proper drain rate.
9.Control valve cycle continuously.	A.Locating signal wiring breakdown. B. Controller is faulty. C. Foreign material stuck the driving gear. D.Time of regeneration steps were set to zero.	A.Check and connect locating signal wiring. B. Replace controller. C. Take out foreign material. D. Check program setting and reset.
10.Drain flows continuously.	A. Internal valve leak. B.When electricity fails to supply, valve stops backwash or rapid rinse position.	A.Check and repair valve body or replace it. B. Adjust valve to service position or turn off bypass valve and restart when electricity supply.
11.Interrupted or irregular brine.	A. Water pressure too low or not stable. B.Injector is plugged or faulty. C. Air in resin tank. D.Floccules in resin tank during backwash.	A. Increase water pressure. B. Clean or replace injector. C. Check and find the reason. D. Clean the floccules in resin tank.
12. Water flow out from drain or brine pipe after regeneration.	A.Foreign material in valve which makes valve can't be closed completely. B. Hard water mixed in valve body. C. Water pressure is too high which result in valve doesn't get the right position. D. Under the Backwash position, the outlet line and brine line are connected.	A.Clean foreign material in valve body. B.Change valve core or sealing ring. C.Reduce water pressure or use pressure release function. D. Install a check valve, solenoid valve in front of the outlet or install a liquid level controller in the brine tank.
13. Salt water in soften water.	A. Foreign material in injector make it fails to work. B.Brine valve cannot be shut-off. C.Time of rapid rinse too short.	A. Clean and repair injector. B. Repair brine valve and clean it. C. Extend rapid rinse time.
14.Unit capacity decreases.	A. Unit fails to regenerate or regenerate not properly. B. Fouled resin bed. C. Salt setting not proper. D.Softener setting not proper. E. Raw water quality deterioration. F.Turbine of flow meter is stuck.	A.Regenerate according to the correct operation requirement. B. Increase backwash flow rate and time, clean or change resin. C. Readjust brine drawing time. D.According to the test of outlet water, recount and reset. E.Regenerate unit by manual temporary, then reset regeneration cycle. F.Disassemble flow meter and clean it or replace a new turbine.


●B. Controller Fault

Problem	Cause	Correction	
All indictors display on front panel.	A.Wiring of front panel with controller fails to work. B. Control board is faulty, C. Transformer damaged. D. Electrical service not stable.	A.Check and replace the wiring. B. Replace control board. C.Check and replace transformer. D.Check and adjust electrical service.	
2.No display on front panel	A.Wiring of front panel with controller fails to work. B. Front panel damaged. C. Control board damaged. D. Electricity is interrupted.	A. Check and replace wiring. B. Replace front panel. C. Replace control board. D. Check electricity.	


3.E1 Flash	A. Wiring of locating board with controller fails to work. B. Locating board damaged. C. Mechanical driven failure. D. Faulty control board. E. Wiring of motor with controller is fault. F. Motor damaged.	A. Replace wiring. B. Replace locating board. C. Check and repair mechanical part. D. Replace control board. E. Replace wiring. F. Replace motor.
4.E2 Flash	A.Hall component on locating board damaged. B. Wiring of locating board with controller fails to work. C. Control board is faulty.	A. Replace locating board. B. Replace wiring. C. Replace control board.
5.E3 or E4 Flash	A. Control board is faulty.	A. Replace control board.

3.8. Assembly & Parts

● Flow Meter Connector & Animated Connector









5457002 Animated Connector

	5447018 Flow Meter						
Item No.	Description	Part No.	Quan tity				
1	Animated Nut	8945001	1				
2	O-ring	8378081	1				
3	Impeller Supporter	5115022	1				

	5457002 Animate	d Connector	
Item No.	Description	Part No.	Qua ntity
1	Animated Nut	8945001	1
2	O-ring	8378081	1
3	Clip	8270004	1

4	Impeller	5436010	1	4	Connector	8458038	1
5	Impeller Supporter	5115021	1				
6	Clip	8270004	1				
7	Shell	8002001	1				






5447020Flow Meter

5457003 Animated Connector

5447020 Flow Mete					
Item No.	Description	Part No.	Quan tity		
1	Connector	8458014	1		
2	O-ring	8378064	1		
3	Impeller Supporter	5115023	1		
4	Impeller	5436013	1		
5	Impeller Supporter	5115024	ã.		
6	Clip	8270005	1		
7	Shell	8002006	1		

Item No.	Description	Part No.	Qua ntity	
1	Connector	8458014	1	
2	O-ring	8378064	1	
3	Clip	8270005	1	
4	Connector	8458039	1	
		1		


•F116A3 Valve Body Assembly



F116A3 Valve Body Components (There is no item No. 35, 36, 37 for F116A1)

Item No.	Description	Part No.	Quantity	Item No.	l Description		Quantity
1	O-ring 73×5.3	8378143	î î	30	30 Shaft		1
2	O-ring 25.8×2.65	8378078	1	31 Moving Seal Ring		8370001	1
2	Valve Body (ABS+GF10)	5022104		32	Moving Disk	8459078	1
3	Valve Body (PPO+GF20)	5022105	1	33	Fixed Disk	8469079	ī
4	Screw, Cross ST3.9×16	8909016	4	34	Seal Ring	8370111	1
5	Motor	6158073	1	35	Animated Connector	5457002	2
6	Screw, Cross M4×16	8902006	4	36	Flow Meter	5447018	1
7	Small Gear, Motor	8241003	1	37	Seal Ring	8371001	2
8	Pin	8993003	1	38	Plug	8323002	1
9	Wire for Power	5513001	1	39	Seal Ring	8370012	1
10	Label	8865002	1	40	Brine Line Flow Control	8468055	1
11	Front Cover	8300001	1	41	O-ring 11×2	8378169	1
12	Seal Ring	8371003	1	42	Connector	8458068	1
13	Display Board	6381003	1	43	Tube	8457004	1
14	Wire for Display Board	5512001	1	44	to be a first and a transfer of the		1
15	Cable Clip	8126004	2	45	45 Animated Nut		Ī
16	Control Board	6382113	1	46	Connector	8458064	1
17	Wire for Locating Board	5511001	1	47	O-ring 15×1.8	8378179	1
18	Screw, Cross ST2.2×6.5	8909004	4	48	Drain Line Flow Control	T	1
19	Dust Cover	8005006	1	49	Clip	8270010	1
20	Probe Wire	6386014	1	50	Screw, Cross M5×35	8902017	2
21	Scre w, Cross ST2.9×16	8909010	4	51	Cover, Injector	8315001	Ĭ
22	Screw, Cross ST3.9×13	8909013	i	52	O-ring 30×1.8	8378025	1
23	Big Gear, Driven	5241023	1	53	Nozzle, Injector	8454009	1
24	Screw, Cross ST2.9×9.5	8909008	7	54			ï
25	Locating Board	6380044	1	55 Injector Body		8008010	1
26	Fitting Nut	8092004	1	56	O-ring		1
27	O-ring 73×3.55	8378128	2	57	O-ring 7.5×1.8	8378016	2
28	O-ring 38.7×3.55	8378184	2				
29	Anti-friction Washer	8216004	1				

•F117A3 Valve Body Assembly



F117A3 Valve Body Components (There is no item No. 35, 36, 37 for F117A1)

Item No.	Description	Part No.	Quantity	Item No.	Description		Quantity
1	O-ring 73×5.3	8378143	1	29	29 Shaft		ij
2	O-ring 25.8×2.65	8378078	1	30	30 Moving Seal Ring		1
3	Valve Body (ABS+GF10)	5022106	1	31	Moving Disk	8370053 8459079	ï
22	Valve Body (PPO+GF20)	5022107			1811.11 .2 14110.		
4	Screw, Cross ST3.9×16	8909016	.4	32	Fixed Disk	8469080	1
5	Seal Washer	8371019	3	33	Seal Ring	8370112	1
6	Plug	8323005	1	34	Animated Connector	5457003	1
7	Motor	6158074	1	35	Flow Meter	5447020	1
8	Screw, Cross M4×16	8902006	4	36	Plug	8323002	1
9	Small Gear, Motor	8241010	1	37	Seal Ring	8370012	1
10	Pin	8993003	Ĭ	38	Brine Line Flow Control	8468055	j j
11	Label	8865004	1	39	O-ring 11×2	8378169	1
12	Front Cover	8300004	1	40	Connector	8458068	1
13	Display Board	6381003	1	41	Tube	8457004	1
14	Control Board	6382113	1	42	Hexagonal Nut	8940001	i
15	Wire for Locating Board	5511001	1	43	Animated Connector	8945025	1
16	Wire for Display Board	5512001	1	44	Connector	8458064	1
17	Screw, Cross ST2.2×6.5	8909004	2	45	O-ring 15×1.8	8378179	1
18	Dust Cover	8005005	1	46	Drain Line Flow Control	8468062	i.
19	Cable Clip	8126004	2	47	Clip	8270010	1
20	Probe Wire	6386014	1	48	Screw, Cross M5×35	8902017	2
21	Wire for Power	5513001	1	49	Cover, Injector	8315001	1
22	Screw, Cross ST3.9×13	8909013	1	50	O-ring 30×1.8	8378025	Ĩ
23	Big Gear, Driven	5241024	1	51	Nozzle, Injector	8454007	1
24	Screw, Cross ST2.9×9.5	8909008	7	52	Throat, Injector	8467007	1
25	Locating Board	6380045	i	53	53 Injector Body		1
26	Fitting Nut	8092007	1	54	O-ring 10.82×1.78	8378012	Ī
27	O-ring 50.39×3.53	8378107	1	55	O-ring 7.5×1.8	8378016	2
28	Anti-friction Washer	8216010	1				

4. Warranty Card

Dear client:

This warranty card is the guarantee proof of RUNXIN brand multi-functional flow control valve. It is kept by client self. You could get the after-sales services from the supplier which is appointed by RUNXIN manufacturer. Please keep it properly. It couldn't be retrieved if lost.

It couldn't be repaired free of charge under the below conditions:

- 1. Guarantee period expired. (One year).
- 2.Damage resulting from using, maintenance, and keeping that are not in accordance with the instruction.
- 3. Damage resulting from repairing not by the appointed maintenance personnel.
- 4. Content in guarantee proof is unconfirmed with the label on the real good or be altered.
- 5.Damage resulting from force majeure.

Product Name	阅新 Multi-functional Flow Control Valve for Water Treatment Systems							
Model	Code of Valve Body							
Purchase Company Name				Tel/Cel	ι.			
Problem								
Solution								
Date of Repairing		Date of Accomplishment				ntenance Signature		

When product need warranty service, please fill in the below content and sent this card together with the product to the appointed suppliers or Runxin company.

End-user Company Name						Tel/	Cel.		
Purchase Company Name						Tel/	Cel.		
Model					Code of Valve Body				
Tank Size φ × Resin				Resin Tank Size L		Raw	Raw Water Hardness mmol/I		
Water Source: Ground-water □ Tap Water □			Water Treatment Capacity m³			Bacl	Backwash Time min		
Brine Rinse Time min Slow Rinse		e Time n	nin	Brine Refill Ti	me mir	Fast	Rinse Time	min	
Problem Description									



WENZHOU RUNXIN MANUFACTURING MACHINE CO., LTD.

ADD: NO.169, RUNXIN ROAD, SHANFU TOWN, WENZHOU, ZHEJIANG, CHINA.
Tel: 0086-577-88630038, 88576512, 85956057 Fax: 0086-577-88633258
http://www.run-xin.com Email:sales@run-xin.com